

APOLLON KISS

LIQUID LIPSTICK
ABIC-5517D



LIPS

IN2025INCOS



OVERVIEW

This non-transfer lip liquid enriched with goodness of Dermacryl® 79, which is a strongest film former that makes this unique formula waterproof and smudge proof. A flexible no-fade film is formed which gives non-transfer, long-lasting effect and is only removed by using a mild cleanser. Amaze® XT is an anionic film-former which serves as both fixative and thickening & suspensive agent. Dry-Flo® TS helps in quick drying, keeping lips soft.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	61,60
	TEA		Triethanolamine	Neutralizer	3,30
	Dermacryl® 79	NOURYON*	Acrylates/Octylacrylamide Copolymer	Film former	8,00
B	Glycerin	/	Glycerin	Humectant	4,00
	Amaze® XT	NOURYON*	Dehydroxanthan Gum	Thickener	0,40
C	Lavanya Elegans	NEELIKON*	Red 7	Color	4,50
	Lavanya Lilac		Red 27		2,00
	Propylene Glycol	/	Propylene Glycol	Humectant	14,00
D	Dry-Flo® TS	NOURYON*	Tapioca Starch, Polymethylsilsesquioxane	Sensory modifier	1,00
	Iscaguard DGP	ISCA*	Pentylene Glycol, Caprylyl Glycol, Decylene Glycol	Preservative	1,20

* Please contact us to know in which country we are supplier of

PROCESS



PHASE A : Heat water up to 80°C then add TEA and stir until dissolved. Sift in Dermacryl® 79 under stirring at 80°C. Continue mixing for 20 minutes at 80°C. Remove heating and compensate for loss of water if any.

PHASE B : Add pre-mixed phase B into phase A and stir until dissolved and completely homogeneous.

PHASE C : Add pre-mixed phase B into phase AB and mix well for 10 minutes.

PHASE D : Add into phase ABC in mentioned sequence and mix well for 10 minutes.

PROPERTIES



APPEARANCE : Red Liquid.

VISCOSITY : 1150 cPs
(Brookfield RVDV-II+, 20 rpm, 1 min, spindle 2).

pH : N/A.